

Town & Country


Automated Garage Door Systems
Overhead • Swinging • Sliding

phone (203) 563-9300

fax (203) 563-9313

Ed Sementini

GARAGE DOOR OPERATOR "UNIVERSAL" PRE-WIRING DIAGRAM



Required:

PRE-WIRING FOR PHOTOELECTRIC SENSORS OR EDGE SENSORS

- 2-CONDUCTOR WIRE (22 GA) FROM LOCATION ① TO EXIT CEILING ABOVE OPERATOR.
- 2-CONDUCTOR WIRE (22 GA) FROM LOCATION ② TO EXIT CEILING ABOVE OPERATOR.

Required:

PRE-WIRING FOR PUSHBUTTON

- 2-CONDUCTOR WIRE (22 GA) FROM LOCATION ③ TO EXIT CEILING ABOVE OPERATOR.

NOTE: CHECK LOCAL BUILDING CODES; ONLY USE UL LISTED MATERIAL.

NOTE: CHECK MANUFACTURERS' PRE-WIRING BULLETINS FOR FURTHER DETAILS.